


Driver of XMOS for windows


Example: on WIN7 64BIT (but my pc is in Chinese, I think others are similar)

First: open the rar file, close the anti-virus softwares

Second: connect the XMOS by USB cable, and click the "setup.exe"

You will see below windows:






Third: setting the audio , on control panel on the computer.(then the XMOS connect to pc by SPDIP)




FOOBAR 2000 setting(plug-in files)


You can select DS or ASIO, here is ASIO setting

Please note below three files I have selected, please copy them to the installation file of Foobar (components)




First: open the preference setting on Foobar200, open the output >ASIO, then click the “Add new”, then select “weiliangHIFI ASIO Driver” this is our XMOS device, then click OK to save





Second: click Output to select Device, you can select “ASIO : WeiliangHiFi ASIO Driver” or “XMOS USB Audio 2.0”



This is the control panel of XMOS

